

HL 033 Sunday Schooled

 Sample ID: BIA250221S0015
 Strain: HL 033 Sunday Schooled

 Produced:
 Collected:
 Received: 02/21/2025
 Completed: 02/27/2025
 Batch#: HL 033 Sunday Schooled

 Client
Forbins Finest
 Lic. # CLTV0087
 21 METRO WAY
 Barre, VT 05641

 Matrix: Plant
 Type: Flower - Cured
 Sample Size: 4.94 g
 Lot#: HL 033 Sunday Schooled


Summary

Test	Date Tested	Result
Sample		Complete
Cannabinoids	02/26/2025	Complete
Moisture	02/24/2025	8.20% - Complete
Water Activity	02/24/2025	0.363 aw - Complete
Terpenes	02/24/2025	Complete

Cannabinoids

Completed

26.79% Total THC	0.07% Total CBD	32.35% Total Cannabinoids
----------------------------	---------------------------	-------------------------------------

Analyte	LOQ	Results	Results	Mass
	mg/g	%	mg/g	mg/serving
CBDVa	0.0005	<LOQ	<LOQ	
CBDV	0.0012	<LOQ	<LOQ	
CBDa	0.0008	0.08	0.8	
CBGa	0.0008	1.55	15.5	
CBG	0.0019	0.17	1.7	
CBD	0.0019	<LOQ	<LOQ	
THCV	0.0021	<LOQ	<LOQ	
CBN	0.0013	<LOQ	<LOQ	
Δ9-THC	0.0020	<LOQ	<LOQ	
Δ8-THC	0.0019	<LOQ	<LOQ	
Δ10-THC	0.0002	<LOQ	<LOQ	
CBC	0.0024	<LOQ	<LOQ	
THCa	0.0034	30.55	305.5	
Total THC		26.79	267.94	
Total CBD		0.07	0.66	
Total		32.35	323.51	0.00

Analyst: 048

Cannabinoids Methodology: High Performance Liquid Chromatography (HPLC) using PerkinElmer FLEXAR™ with Photo Diode Array Detector (PDA)

Total CBD and total THC are calculated values, to account for assumed decarboxylation from the acid form (THCA or CBDA) to the neutral form, causing weight loss of the acid group. These values are calculated as follows:

$$\text{Total THC} = (\text{THCA} \times 0.877) + \Delta 9\text{-THC}$$

$$\text{Total CBD} = (\text{CBDA} \times 0.877) + \text{CBD Reagent}$$

Blanks: < LOQs for all analytes

LOQ = The lowest quantity that this method can reliably detect. Any cannabinoid that was not detected is assumed to be less than the stated LOQ (<LOQ).

All results reflect dry weight of material, based on % moisture of the sample.

Measurement of Uncertainty (MU): the parameter, associated with the result of a measurement, that characterizes the dispersion of the values that could reasonably be attributed to the particular quantity subject to measurement. Δ9-THC MU = ±0.005% Total THC MU = ±0.007%

All other cannabinoid MU values are available upon request.

All moisture and water activity analysis is determined by dewpoint measurement using an AQUALAB water activity meter.




 Luke Emerson-Mason
 Laboratory Director
 02/27/2025

 Confident LIMS
 All Rights Reserved
 coa.support@confidentlims.com
 (866) 506-5866
 www.confidentlims.com


HL 033 Sunday Schooled

 Sample ID: BIA250221S0015
 Strain: HL 033 Sunday Schooled

 Produced:
 Collected:
 Received: 02/21/2025
 Completed: 02/27/2025
 Batch#: HL 033 Sunday Schooled

 Client
Forbins Finest
 Lic. # CLTV0087
 21 METRO WAY
 Barre, VT 05641

 Matrix: Plant
 Type: Flower - Cured
 Sample Size: 4.94 g
 Lot#: HL 033 Sunday Schooled

Terpenes

Completed

Analyte	LOQ	Results	Results
	mg/g	mg/g	%
Limonene	0.010	4.324	0.432
Ocimene	0.010	2.222	0.222
Linalool	0.010	1.873	0.187
β-Myrcene	0.010	1.518	0.152
β-Caryophyllene	0.010	1.203	0.120
β-Pinene	0.010	0.809	0.081
α-Pinene	0.010	0.487	0.049
Terpinolene	0.010	0.440	0.044
α-Humulene	0.010	0.338	0.034
Camphene	0.010	0.106	0.011
α-Bisabolol	0.010	0.056	0.006
3-Carene	0.010	<LOQ	<LOQ
α-Terpinene	0.010	<LOQ	<LOQ
Caryophyllene Oxide	0.010	<LOQ	<LOQ
cis-Nerolidol	0.010	<LOQ	<LOQ
Eucalyptol	0.010	<LOQ	<LOQ
γ-Terpinene	0.010	<LOQ	<LOQ
Geraniol	0.010	<LOQ	<LOQ
Guaiol	0.010	<LOQ	<LOQ
Isopulegol	0.010	<LOQ	<LOQ
p-Cymene	0.010	<LOQ	<LOQ
trans-Nerolidol	0.010	<LOQ	<LOQ
Total		13.376	1.338

Primary Aromas



Analyst: 048

LOQ = The lowest quantity this method can reliably detect. Any terpene that was not detected is assumed to be less than the stated LOQ (<LOQ).

Terpene Methodology: Headspace Sampler, Gas Chromatography-Mass Spectrometry (GC-MS), using Perkin Elmer Clarus® SQ8 GC MS

Reagent Blanks: < LOQs for all analytes

All results reflect dry weight of material, based on % moisture of the sample.

All moisture and water activity analysis is determined by dewpoint measurement using an AQUALAB water activity meter.




 Luke Emerson-Mason
 Laboratory Director
 02/27/2025

 Confident LIMS
 All Rights Reserved
coa.support@confidentlims.com
 (866) 506-5866
www.confidentlims.com
